



Aktiv³ Belt Bag

Grows with the content!

The practical and extremely stretchy bag adapts optimally to all contents and is worn so comfortably over the hips that you hardly notice it. When running, walking, cycling or travelling, various utensils such as a mobile telephone, wallet, keys or snacks bars and liquids can be transported easily and conveniently and are always at hand. Incl. detachable start number holder.



www.aktiv3.de

Art. No.: 2543

As at: 0713